















Outdoor Fisheye Camera Accessory




FE9380-HV
FE9382-EHV-v2
FE9391-EHV-v2

Mounting Type	Item	Number	Description	Image
 Pendant Mount	AM-114	1	Pendant Head (Outdoor)	
	AM-116	1	Pendant Pipe (20 cm) (1.5" PS11) (Optional)	
	AM-117	1	Pendant Pipe (40 cm) (1.5" PS11) (Optional)	
	AM-525	1	Mounting Adapter for Outdoor Dome (3/4" NPT Female Connector & 1-1/2" NPT Male Connector)	

Mounting Type	Item	Number	Description	Image
 Wall/Pole/Corner Mount(1)	AM-116	1	Pendant Pipe (20 cm) (1.5" PS11) (Optional)	
	AM-117	1	Pendant Pipe (40 cm) (1.5" PS11) (Optional)	
	AM-525	1	Mounting Adapter for Outdoor Dome (3/4" NPT Female Connector & 1-1/2" NPT Male Connector)	
	AM-221	1	Gooseneck Bracket	
	AM-718	1	Junction Box (Optional)	
	AM-314	Pole Mount Adapter		
	AM-315	Pole Mount Adapter		
	AM-414	Corner Mount Adapter		

* AM-314/ AM-315/ AM-414 Cannot be used together



Mounting Type	Item	Number	Description	Image
<p>Wall/Pole/Corner Mount(2)</p>	AM-116	1	Pendant Pipe (20 cm) (1.5" PS11) (Optional)	
	AM-117	1	Pendant Pipe (40 cm) (1.5" PS11) (Optional)	
	AM-525	1	Mounting Adapter for Outdoor Dome (3/4" NPT Female Connector & 1-1/2" NPT Male Connector)	
	AM-218	1	Wall Mount Bracket	
	AM-719	1	Outdoor Junction Box (Optional)	
	AM-312	Pole Mount Adapter		
	AM-315	Pole Mount Adapter		
	AM-412	Corner Mount Adapter		

* AM-312 and AM-315 Cannot be used together

Mounting Type	Item	Number	Description	Image
<p>L-Shape Wall Mount</p>	AM-210	1	Wall Mount Bracket	